

Rekluse Motor Sports z-Start Pro Tuning Chart RMS-826 450/501/550 Husaberg

Manual Revision: 022107
198-826

z-Start Pro

Engagement RPM	Engagement Rate	2 Inch Black Spring (C200-L7)	Shorter 2 Inch Red Spring (C200-M3)	Taller 2 Inch Red Spring (C200-M4)	# of TC Balls	# of steel Balls
Low	Harder	X			15	12
Medium*	Harder		X		15	12
High	Harder			X	15	12
Low	Softer	X			12	15
Medium*	Softer		X		12	15
High	Softer			X	12	15

* Recommend initial settings

Note: TC balls must be evenly spaced around the pressure plate.

The pattern for the 15 TC ball setup is **5 TC balls followed by 4 steel balls**.

The pattern for the 12 TC ball setup is **4 TC balls followed by 5 steel balls**.

TC Balls are darker in color and about twice as heavy as steel balls. Another way to distinguish between steel balls and the heavier TC balls is to use a low powered magnet (magnetic screwdriver works well). With a low powered magnet, the TC balls do not seem magnetic.