

Rekluse Motor Sports

The z-Start™ 2-Finger Clutch

Installation Guide

Copyright 2002 Rekluse Motor Sports
RMS220 – 2-Finger Clutch Override

RMS220-200
Manual Revision: 101804

Rekluse Motor Sports, Inc.
110 E. 43rd Street
Boise, Idaho 83714
208-426-0659
support@rekluse.com

Installation:

1. Remove the reservoir cap from the Rekluse Left Hand Master Cylinder—the two screws will be re-used when the 2-Finger Clutch Cap is installed.
2. Remove the rubber diaphragm from the reservoir cap and install it on the 2-Finger Clutch Cap.
3. Attach the 2-Finger Clutch Cap to the Rekluse Left Hand Master Cylinder with the two screws that were removed in Step 1.
4. Attach the clutch cable end to the 2-Finger Clutch Lever and pull the cable through the 2-Finger Clutch Cap's cable slack adjuster.
5. Ensure that the z-Start Perch Adjuster indexes into the 2-Finger Clutch Cap's cable slack adjuster.
6. Making use of the 2-Finger Clutch Cap's cable slack adjuster, adjust and set the cable slack as outlined in the z-Start Perch Adjuster Manual.

Maintenance:

Periodically inspect the screws attaching the 2-Finger Clutch Cap to the Rekluse Left Hand Master Cylinder to ensure it remains tightly fastened. Also, ensure that the screw attaching the Lever to the 2-Finger Clutch Cap remains securely fastened.