

# Rekluse Motor Sports z-Start Pro Tuning Chart Honda CR-500

198-817

Manual Revision: 042707

## z-Start Pro

Engagement RPM	Engagement Rate	2 Inch Black Spring (C200-L5)	1.5 Inch Black Spring (C150-L4)	1.5 Inch Red Spring (C150-M3)	Number of Tungsten Carbide Balls	Number of Steel Balls
Low	Harder	X	X		6	21
<b>Medium*</b>	<b>Harder</b>	X		X	<b>6</b>	<b>21</b>
Low	Softer	X	X		3	24
<b>Medium*</b>	<b>Softer</b>	X		X	<b>3</b>	<b>24</b>

**\*Recommend initial settings**

**Note:** TC balls must be evenly spaced around the pressure plate.

The pattern for the 6 TC ball setup is **2 TC balls followed by 7 steel balls.**

The pattern for the 3 TC ball setup is **1 TC ball followed by 8 steel balls.**

To distinguish between steel balls and the heavier TC balls use a low powered magnet (magnetic screwdriver works well). With a low powered magnet, the TC balls do not seem magnetic.