

Rekluse Motor Sports z-Start Pro Tuning Chart KTM-RFS

198-833

Manual Revision: 051707

z-Start Pro

Engagement RPM	Engagement Rate	2 Inch Shorter Black Spring (C200-L6)	2 Inch Taller Black Spring (C200-L7)	2 Inch Red Spring (C200-M3)	# of Balls
Low	Harder	X			27
Medium*	Harder		X		27
High	Harder			X	27
Low	Softer	X			24
Medium*	Softer		X		24
High	Softer			X	24

*** Recommend initial settings**

Note: Empty ball slots must be evenly spaced around the pressure plate.

The pattern for the **24 ball setup** is **8 balls followed by 1 empty slot**.