

Rekluse Motor Sports z-Start Pro Tuning Chart KTM 250/300/380 2-Stroke

198-835

Manual Revision: 012308

z-Start Pro

Engagement RPM	Engagement Rate	2 Inch Black Spring C200L5(shorter)	2 Inch Black Spring C200L6 (taller)	2 Inch Red Spring C200M3 (shortest)	# of Balls	# of TC Balls
Low	Harder	X			24	3
Medium*	Harder		X		24	3
High	Harder			X	24	3
Low	Softer	X			27	0
Medium*	Softer		X		27	0
High	Softer			X	27	0

Note: TC balls must be evenly spaced around the pressure plate.

The pattern for the 3 TC ball setup is **1 TC ball followed by 8 steel balls.**